MODEL: 93426BS
PACKING DIAGRAM





MODEL: 93426BS

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FIXTURE SHOULD TAKE APPROXIMATELY 5 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

TOOLS: YOU WILL NEED THE FOLLOWING TOOLS OR EQUIPMENT: LADDER, SCREWDRIVER, ADJUSTABLE WRENCH, WIRE CUTTERS.

UNPACK THE FIXTURE

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: CANOPY ASSEMBLY, (3) EXTENSION TUBES, CUP ASSEMBLY AND GLASS SHADE. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

MOUNTING HARDWARE PACKAGE:
(2) 8–32 x 1–1/4" SCREWS AND (5) WIRE CONNECTORS.

FIXTURE ASSEMBLY

1. REMOVE CROSS BAR FROM TOP OF THE CANOPY BY UNSCREWING (2) BALL FINIALS.

2. FEED WIRE UP THROUGH EXTENSION TUBES AND WORKING UPWARDS TOWARD CANOPY AS SHOWN.

3. SCREW EXTENSION TUBE TO TOP OF THE CUP. (USE ANY SINGLE LENGTH OF EXTENSION TUBE OR CONNECT TUBE SECTIONS TOGETHER TO OBTAIN DESIRED LENGTH.)

4. SCREW EXTENSION TUBE TO SWIVEL ON CANOPY.

5. CUT OFF THE CORD TO KEEP THE CORD 6" FROM CENTER OF THE CANOPY.

6. SPLIT THE END OF THE POWER SUPPLY WIRE 3–1/2" FROM THE END AND STRIP THE PLASTIC COVER OFF THE WIRE ABOUT 1/2".

7. REMOVE (3) FINIALS FROM THE CUP BY UNSCREWING THE FINIALS.

STOP COMPLETE INSTALLATION INSTRUCTIONS ON NEXT PAGE BEFORE CONTINUING TO FINAL ASSEMBLY.

FINAL ASSEMBLY

1. PLACE THE GLASS SHADE TO BOTTOM OF THE CUP AND SECURE WITH (3) FINIALS REMOVED ABOVE.

2. RESTORE POWER, YOUR NEW FIXTURE IS NOW READY FOR USE.



NOTE: THE DRIVER IS SHOW OUTSIDE OF THE CANOPY FOR EASY UNDERSTANDING OF WIRE CONNECTION.
THIS DRIVER IS INSIDE OF THE CANOPY.

INSTALLATION INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

CAUTION: TO AVOID POSSIBLE ELECTRIC SHOCK, MAKE SURE THE ELECTRICITY IS SHUT OFF AT THE MAIN PANEL. IF YOU ARE REPLACING AN EXISTING FIXTURE, FIRSTLY, TURN THE FIXTURE OFF. NEXT, TURN THE WALL SWITCH OFF. FINALLY, GO TO THE MAIN FUSE OR BREAKER BOX IN YOUR HOME. TURN THE FUSE OR BREAKER TO THE OFF POSITION. SOME TYPES OF FUSES MUST BE UNSCREWED TO SHUT OFF THE POWER.

* ALL WIRING MUST BE DONE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES.

** IF YOU ARE NOT FAMILIAR WITH WIRING, YOU SHOULD USE A QUALIFIED ELECTRICIAN.

*** THIS FIXTURE IS INTENDED TO BE MOUNTED TO A UL LISTED OUTLET BOX CAPABLE OF SUPPORTING THE FIXTURE.

COMPLETE FIXTURE ASSEMBLY INSTRUCTIONS FIRST (SEE PREVIOUS).

1. ATTACH THE CROSS BAR TO THE CEILING OUTLET BOX USING THE TWO SCREWS PROVIDED WITH THE OUTLET BOX. (NOTE: IF THE SCREWS WITH THE OUTLET BOX ARE TOO SHORT, USE THE (2) 8–32 x 1–1/4" SCREWS PROVIDED IN THE MOUNTING HARDWARE PACKAGE).

2. CONNECT THE WIRE FROM FIXTURE WAS MARKED "+" IN RED LABEL TO THE RED WIRE FROM THE OUTPUT SIDE OF THE DRIVER USING THE TWIST–ON WIRE CONNECTORS PROVIDED.

3. CONNECT THE WIRE FROM FIXTURE WAS MARKED "–" IN BLACK LABEL TO THE BLACK WIRE FROM THE OUTPUT SIDE OF THE DRIVER USING THE TWIST–ON WIRE CONNECTORS PROVIDED.

4. CONNECT THE WHITE SUPPLY WIRE TO THE WHITE WIRE FROM THE INPUT SIDE OF THE DRIVER USING THE TWIST–ON WIRE CONNECTORS PROVIDED.

5. CONNECT THE BLACK SUPPLY WIRE TO THE BLACK WIRE FROM THE INPUT SIDE OF THE DRIVER USING THE TWIST–ON WIRE CONNECTORS PROVIDED.

6. INSTALL THE FIXTURE GROUND WIRE UNDER THE GREEN GROUND SCREW ON THE CROSS BAR THEN CONNECT THE FIXTURE GROUND WIRE TO THE SUPPLY GROUND WIRE IN THE OUTLET BOX USING THE TWIST–ON WIRE CONNECTOR PROVIDED.

7. TUCK THE WIRES CAREFULLY INSIDE THE OUTLET BOX. SPREAD THE ELECTRICAL SPLICES SO THAT THE BLACK WIRES ARE ON ONE SIDE OF THE OUTLET BOX AND THE WHITE WIRES ARE ON THE OTHER SIDE.

8. RAISE THE CANOPY ASSEMBLY TO THE CEILING AND SECURE IN PLACE WITH (2) BALL FINIALS.

9. SEE PREVIOUS PAGE FOR FINAL ASSEMBLY INSTRUCTIONS.